Assignment 6.2 – RDS

Today's tasks:

1. Query to RDS from EC2

Submit items below in one pdf file:

1. Screenshot of query executions from EC2 on RDS.

Instruction 1 – Create an RDS and connect from an EC2

- 1. Create an IAM role for your EC2 that has Amazon RDS Data access
 - a. Go to IAM -> Roles -> Create Role
 - Select type of trusted entity (AWS Service is selected by default) -> Select EC2 -> Click Next permissions
 - c. Look for AmazonRDSDataFullAccess. Select it. Then next tags. Then next review.
 - d. Give a role a name and click create role button.
 - e. Add this IAM role to an existing EC2 instance or select when creating a new EC2 instance in public subnet
- 2. Create database subnet
 - a. Go to RDS -> In sidebar, there is Subnet groups, click on that -> click Create DB subnet group.
 - b. Give it a name and description.
 - c. Select your VPC
 - d. Select AZ us-east-1a and us-east-1b
 - e. Select private subnets in those AZs -> Hit create.
- 3. Create database SG Allow inbound access from the EC2
 - a. Go to EC2 -> In sidebar, there is Security groups, click on that -> Click Create Security Group
 - b. Give name as MyRdsSg -> give description -> select your VPC
 - c. In inbound rules section, click on add rule
 - d. Click on Type -> Look for MYSQL/Aurora
 - e. Source -> select the SG of the web server that accesses to the database -> Create Security Group
- 4. Create RDS database
 - a. Templates -> select dev/test
 - b. Enter master password. That you will use when logging to the DB. Username is admin.
 - c. DB instance class -> Select Burstable classes -> Select db.t3.small
 - d. Availability & durability -> Create an Aurora Replica
 - e. Select Create an Aurora Replica or Reader node in a different AZ in Availability & Durability section.
 - f. Select your VPC, it will automatically select the subnet. Select SG as well.
 - g. you must uncheck this default setting in the Additional configuration / Monitoring panel
- 5. Install mysql client on EC2

```
sudo yum install mysql -y
mysql -h my-database-1.cluster-cqc7tbzm3eby.us-east-1.rds.amazonaws.com -P
3306 -u root -p
show databases;
create database university;
   6. Create database, table
CREATE TABLE TEACHER (
    TEACHER ID int,
    NAME varchar(255)
);
CREATE TABLE COURSE (
    COURSE_ID int,
    COURSE_CODE varchar(255),
    COURSE NAME varchar(255),
      TEACHER_ID int
);
   7. Insert data into it and select it.
INSERT INTO TEACHER (TEACHER_ID, NAME)
VALUES (1, "UNUBOLD"),
(2, "ASAAD"),
(3, "UMUR");
INSERT INTO COURSE (COURSE_ID, COURSE_CODE, COURSE_NAME, TEACHER_ID)
VALUES (1, "CS516", "CLOUD COMPUTING", 1),
(2, "CS568", "React", 1),
(3, "CS569", "Angular", 1),
(3, "CS569", "Angular", 2);
   8. Retrieve data
SELECT TEACHER.NAME, COURSE.COURSE_ID, COURSE.COURSE_NAME
FROM TEACHER JOIN COURSE ON TEACHER.TEACHER ID = COURSE.TEACHER ID;
```

Refer: Connecting to a DB instance running the MySQL database engine